



## Bracke P11.a Planter

The Bracke P11.a makes it possible to conduct the full scope of regeneration work from scarification to planting with a single machine. The Bracke P11.a provides regeneration of the highest quality with the greatest possible consideration for environmental and ecological aspects.

### Function

Normally, the Bracke P11.a makes a mound of inverted humus, compacts it and sets the plants in the middle of the mound. Mounding is the preferred planting method for most soil types. It is even possible to vary the scarification by raking the ground with the head's bucket, to make scarification patches, or to plant directly without scarification. All functions are easily controlled from the cab. Whatever the scarification method, the operator can make allowances for naturally regenerating plants and ecological conditions, as well as cultural aspects and relics.

### Control system

All functions are controlled from the driver's cab using the system computer. The operator receives information such as plant pipe mode, the number of seedlings left in the tray, water consumption, etc. via the display in the cab. Planting depth, compaction, and other variables are easily adjusted via the display. The control system stores operating data such as the number of seedlings planted, working hours and production per hour. The display also includes diagnostics tools such as a list of disruptions and troubleshooting functions.

### Targeted planting

The Bracke P11.a delivers effective scarification and planting on all types of soil, from easily worked and fertile ground to stony fields covered in slash. The operator can choose the planting spot for each individual plant and even decide how the planting spots are formed.

### Bracke Forest AB

Svedjegatan 11, SE 843 31 Bräcke, Sweden



Phone: +46 693-105 75, [info@brackeforest.com](mailto:info@brackeforest.com), [www.brackeforest.com](http://www.brackeforest.com)

## Technical data

|                             |                            |
|-----------------------------|----------------------------|
| Prime mover                 | Excavator 14 – 20 ton      |
| Weight                      | 1 100 kg                   |
| Hydraulic pressure          | 125 bar                    |
| Hydraulic flow              | min 100 l/min              |
| Plant type                  | Covered root plants        |
| Plant magazine & plant pipe | Standard 60 mm (72 plants) |
| Option                      | 50 mm magazine (88 plants) |
| Option                      | 70 mm (62 plants)          |
| Bucket                      | Standard 600 mm            |
|                             | Option 500 mm              |
| Electrical system           | 24 V                       |
| Control system              | PLC based                  |
| Productivity per hour       | Up to 300 plants           |
| Accessories                 | Equipment for additives    |



PLC-based control system.



*The P11.a provides regeneration of the highest quality and with the greatest possible consideration for biological aspects.*



*The P11.a both scarifies and plants.*



*The P11.a plants at the same depth in the center of each mound every time for the best production and survival.*

## Bracke Forest AB

Svedjegatan 11, SE 843 31 Bräcke, Sweden

Phone: +46 693-105 75, [info@brackeforest.com](mailto:info@brackeforest.com), [www.brackeforest.com](http://www.brackeforest.com)